



GW376 and GW377 Splice Join Installation

Insert the splice join halfway into the handrail/kneerail tube.

Fix 2 x 20mm Tek Screws through the tube into the splice join.

Slide the next section of handrail/kneerail tube over the splice join and fix with another 2 x 20mm Tek Screws.

