



SENTRY Corner Elbow Installation

Insert the corner elbow into the handrail extrusion and fix with 1 x 20mm tek screw from the underside. Slide the adjacent handrail tube section onto the elbow then secure using 1 x 20mm tek screw as before.

Repeat above process for the kneerail elbow however the tek screws are fixed into the front recess.

