



GW387 - Closure Bend Kit

Cut the Handrail tube flush with the post (Note, this is the preferred option but it not critical - MAX overhand of top handrail tube - 300mm)
Ensure the kneerail is protruding approx 200mm.

Insert splice swection into handrail section and fix with 2 x 20mm tek screws

Slide Kneerail reducer over kneerail tube

Slide Closure Bend over splice and kneerail reducer

Fix 2 x aluminium rivets through top of closure bend and into splice join.

Fix a 20mm tek screw through closure bend and kneerail reducer underneath.

